



**DIEL
EQUIPOS
INDUSTRIALES**



CATÁLOGO

Conexiones y mangueras

neumáticas

CONEXIONES

XPC



MODEL(φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPC 04-M5	XPC 06-04	XPC 12-02	XPC 1/4-01	XPC 3/8-04	XPC 5/32-U	XPC 1/4-N2	XPC 1/2-N2
XPC 04-M6	XPC 08-01	XPC 12-03	XPC 1/4-02	XPC 1/2-02	XPC 5/32-N1	XPC 1/4-N3	XPC 1/2-N3
XPC 04-01	XPC 08-02	XPC 12-04	XPC 1/4-03	XPC 1/2-03	XPC 5/32-N2	XPC 5/16-N1	XPC 1/2-N4
XPC 04-02	XPC 08-03	XPC 14-03	XPC 5/16-01	XPC 1/2-04	XPC 3/16-U	XPC 5/16-N2	
XPC 06-M5	XPC 08-04	XPC 14-04	XPC 5/16-02		XPC 3/16-N1	XPC 5/16-N3	
XPC 06-M6	XPC 10-01	XPC 16-03	XPC 5/16-03		XPC 3/16-N2	XPC 3/8-N1	
XPC 06-01	XPC 10-02	XPC 16-04	XPC 3/8-01		XPC 3/16-N3	XPC 3/8-N2	
XPC 06-02	XPC 10-03		XPC 3/8-02		XPC 1/4-U	XPC 3/8-N3	
XPC 06-03	XPC 10-04		XPC 3/8-03		XPC 1/4-N1	XPC 3/8-N4	

XPL



MODEL(φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPL 04-M5	XPL 06-04	XPL 12-02	XPL 1/4-01	XPL 3/8-04	XPL 5/32-U	XPL 1/4-N2	XPL 1/2-N2
XPL 04-M6	XPL 08-01	XPL 12-03	XPL 1/4-02	XPL 1/2-02	XPL 5/32-N1	XPL 1/4-N3	XPL 1/2-N3
XPL 04-01	XPL 08-02	XPL 12-04	XPL 1/4-03	XPL 1/2-03	XPL 5/32-N2	XPL 5/16-N1	XPL 1/2-N4
XPL 04-02	XPL 08-03	XPL 14-03	XPL 5/16-01	XPL 1/2-04	XPL 3/16-U	XPL 5/16-N2	
XPL 06-M5	XPL 08-04	XPL 14-04	XPL 5/16-02		XPL 3/16-N1	XPL 5/16-N3	
XPL 06-M6	XPL 10-01	XPL 16-03	XPL 5/16-03		XPL 3/16-N2	XPL 3/8-N1	
XPL 06-01	XPL 10-02	XPL 16-04	XPL 3/8-01		XPL 3/16-N3	XPL 3/8-N2	
XPL 06-02	XPL 10-03		XPL 3/8-02		XPL 1/4-U	XPL 3/8-N3	
XPL 06-03	XPL 10-04		XPL 3/8-03		XPL 1/4-N1	XPL 3/8-N4	

XPE



MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPE 04	XPE 5/32
XPE 06	XPE 3/16
XPE 08	XPE 1/4
XPE 10	XPE 5/16
XPE 12	XPE 3/8
XPE 14	XPE 1/2
XPE 16	

XPU



MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPU 04	XPU 5/32
XPU 06	XPU 3/16
XPU 08	XPU 1/4
XPU 10	XPU 5/16
XPU 12	XPU 3/8
XPU 14	XPU 1/2
XPU 16	

XPV



MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPV 04	XPV 5/32
XPV 06	XPV 3/16
XPV 08	XPV 1/4
XPV 10	XPV 5/16
XPV 12	XPV 3/8
XPV 14	XPV 1/2
XPV 16	

XPY



MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPY 04	XPY 5/32
XPY 06	XPY 3/16
XPY 08	XPY 1/4
XPY 10	XPY 5/16
XPY 12	XPY 3/8
	XPY 1/2

XPCF



MODEL (φ D-T)

Tube(Metric)-Thread(RC)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)	
XPCF 04-01	XPCF 10-01		XPCF 1/4-01		XPCF 5/32-N1	XPCF 3/8-N2
XPCF 04-02	XPCF 10-02		XPCF 1/4-02		XPCF 5/32-N2	XPCF 3/8-N3
XPCF 06-01	XPCF 10-03		XPCF 5/16-01		XPCF 3/16-N1	XPCF 1/2-N2
XPCF 06-02	XPCF 10-04		XPCF 5/16-02		XPCF 3/16-N2	XPCF 1/2-N3
XPCF 06-03	XPCF 12-02		XPCF 3/8-02		XPCF 1/4-N1	
XPCF 08-01	XPCF 12-03		XPCF 3/8-03		XPCF 1/4-N2	
XPCF 08-02	XPCF 12-04				XPCF 5/16-N1	
XPCF 08-03	XPCF 16-03				XPCF 5/16-N2	
XPCF 08-04	XPCF 16-04				XPCF 5/16-N3	

XJSC



MODEL (φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XJSC 04-M5	XJSC 06-04	XJSC 10-03	XJSC 1/4-M5	XJSC 5/16-02	XJSC 5/32-U	XJSC 1/4-N1	XJSC 3/8-N2
XJSC 04-01	XJSC 08-01	XJSC 10-04	XJSC 1/4-01	XJSC 5/16-03	XJSC 5/32-N1	XJSC 1/4-N2	XJSC 3/8-N3
XJSC 04-02	XJSC 08-02	XJSC 12-02	XJSC 1/4-02	XJSC 3/8-02	XJSC 3/16-U	XJSC 1/4-N3	XJSC 3/8-N4
XJSC 06-M5	XJSC 08-03	XJSC 12-03	XJSC 5/16-01	XJSC 3/8-03	XJSC 3/16-N1	XJSC 5/16-N1	XJSC 1/2-N3
XJSC 06-01	XJSC 08-04	XJSC 12-04			XJSC 3/16-N2	XJSC 5/16-N2	XJSC 1/2-N4
XJSC 06-02	XJSC 10-01				XJSC 3/16-N3	XJSC 5/16-N3	
XJSC 06-03	XJSC 10-02				XJSC 1/4-U	XJSC 5/16-N4	

XPB



MODEL (φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPB 04-M5	XPB 06-04	XPB 12-02	XPB 1/4-01	XPB 3/8-04	XPB 5/32-U	XPB 1/4-N2	XPB 1/2-N2
XPB 04-M6	XPB 08-01	XPB 12-03	XPB 1/4-02	XPB 1/2-02	XPB 5/32-N1	XPB 1/4-N3	XPB 1/2-N3
XPB 04-01	XPB 08-02	XPB 12-04	XPB 1/4-03	XPB 1/2-03	XPB 5/32-N2	XPB 5/16-N1	XPB 1/2-N4
XPB 04-02	XPB 08-03	XPB 14-03	XPB 5/16-01	XPB 1/2-04	XPB 3/16-U	XPB 5/16-N2	
XPB 06-M5	XPB 08-04	XPB 14-04	XPB 5/16-02		XPB 3/16-N1	XPB 5/16-N3	
XPB 06-M6	XPB 10-01	XPB 16-03	XPB 5/16-03		XPB 3/16-N2	XPB 3/8-N1	
XPB 06-01	XPB 10-02	XPB 16-04	XPB 3/8-01		XPB 3/16-N3	XPB 3/8-N2	
XPB 06-02	XPB 10-03		XPB 3/8-02		XPB 1/4-U	XPB 3/8-N3	
XPB 06-03	XPB 10-04		XPB 3/8-03		XPB 1/4-N1	XPB 3/8-N4	

XPD



MODEL (φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPD 04-M5	XPD 06-04	XPD 12-02	XPD 1/4-01	XPD 3/8-04	XPD 5/32-U	XPD 1/4-N2	XPD 1/2-N2
XPD 04-M6	XPD 08-01	XPD 12-03	XPD 1/4-02	XPD 1/2-02	XPD 5/32-N1	XPD 1/4-N3	XPD 1/2-N3
XPD 04-01	XPD 08-02	XPD 12-04	XPD 1/4-03	XPD 1/2-03	XPD 5/32-N2	XPD 5/16-N1	XPD 1/2-N4
XPD 04-02	XPD 08-03	XPD 14-03	XPD 5/16-01	XPD 1/2-04	XPD 3/16-U	XPD 5/16-N2	
XPD 06-M5	XPD 08-04	XPD 14-04	XPD 5/16-02		XPD 3/16-N1	XPD 5/16-N3	
XPD 06-M6	XPD 10-01	XPD 16-03	XPD 5/16-03		XPD 3/16-N2	XPD 3/8-N1	
XPD 06-01	XPD 10-02	XPD 16-04	XPD 3/8-01		XPD 3/16-N3	XPD 3/8-N2	
XPD 06-02	XPD 10-03		XPD 3/8-02		XPD 1/4-U	XPD 3/8-N3	
XPD 06-03	XPD 10-04		XPD 3/8-03		XPD 1/4-N1	XPD 3/8-N4	

XPA



φ D

MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPA 04	XPA 5/32
XPA 06	XPA 3/16
XPA 08	XPA 1/4
XPA 10	XPA 5/16
XPA 12	XPA 3/8
	XPA 1/2

XPP



φ D

MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPP 04	XPP 5/32
XPP 06	XPP 3/16
XPP 08	XPP 1/4
XPP 10	XPP 5/16
XPP 12	XPP 3/8
XPP 16	XPP 1/2

XPX



φ D

MODEL(φ D-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPX 04-M5	XPX 06-04	XPX 12-02	XPX 1/4-01	XPX 3/8-04	XPX 5/32-U	XPX 1/4-N2	XPX 1/2-N2
XPX 04-M6	XPX 08-01	XPX12-03	XPX 1/4-02	XPX 1/2-02	XPX 5/32-N1	XPX 1/4-N3	XPX 1/2-N3
XPX 04-01	XPX 08-02	XPX 12-04	XPX 1/4-03	XPX 1/2-03	XPX 5/32-N2	XPX 5/16-N1	XPX 1/2-N4
XPX 04-02	XPX 08-03		XPX 5/16-01	XPX 1/2-04	XPX 3/16-U	XPX 5/16-N2	
XPX 06-M5	XPX 08-04		XPX 5/16-02		XPX 3/16-N1	XPX 5/16-N3	
XPX 06-M6	XPX 10-01		XPX 5/16-03		XPX 3/16-N2	XPX 3/8-N1	
XPX 06-01	XPX 10-02		XPX 3/8-01		XPX 3/16-N3	XPX 3/8-N2	
XPX 06-02	XPX 10-03		XPX 3/8-02		XPX 1/4-U	XPX 3/8-N3	
XPX 06-03	XPX 10-04		XPX 3/8-03		XPX 1/4-N1	XPX 3/8-N4	

XPGJ



φ D1

φ D2

MODEL(φ D1-φ D2)

Tube(Metric)	Tube(Metric)-Tube(Inch)	Tube(Inch)-Thread(NPT)
XPGJ 06-04	XPGJ 08-1/4	XPGJ 1/4-5/32
XPGJ 08-04	XPGJ 10-1/4	XPGJ 5/16-5/32
XPGJ 08-06	XPGJ 10-5/16	XPGJ 5/16-1/4
XPGJ 10-06	XPGJ 12-1/4	XPGJ 3/8-1/4
XPGJ 10-08	XPGJ 12-5/16	XPGJ 3/8-5/16
XPGJ 12-06		XPGJ 1/2-1/4
XPGJ 12-08		XPGJ 1/2-5/16
XPGJ 12-10		XPGJ 1/2-3/8

XPM



φ D

MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPM 04	XPM 5/32
XPM 06	XPM 3/16
XPM 08	XPM 1/4
XPM 10	XPM 5/16
XPM 12	XPM 3/8
XPM 14	XPM 1/2
XPM 16	

XPA




φ D

MODEL(φ D)

Tube(Metric)	Tube(Inch)
XPA 04	XPA 5/32
XPA 06	XPA 3/16
XPA 08	XPA 1/4
XPA 10	XPA 5/16
XPA 12	XPA 3/8
	XPA 1/2

MANGUERAS


MANGUERA DE POLIURETANO (PU TUBE)



Model	D1 (mm)	D2 (mm)	L (m)	Min. working pressure at 20°C (Bar)	Min. burst pressure at 20°C (Bar)	Min. bend radius at 20°C (mm)	Net weight (Kg/Roll)
PU0302	3	2	200	10	30	10	1.4
PU0425	4	2.5	200	10	30	10	1.9
PU0604	6	4	200	10	30	15	3.9
PU0855	8	5.5	100	8	24	20	3.3
PU0805	8	5	100	10	30	20	3.8
PU1065	10	6.5	100	10	30	30	5.6
PU1208	12	8	100	10	30	35	7.8
PU1410	14	10	100	8	24	55	9.4
PU1612	16	12	100	8	24	65	11
PU5/32	3.94	2.5	200	10	30	10	1.9
PU1/4	6.35	4.23	200	10	30	15	4.4
PU5/16	7.94	5	100	10	30	20	3.8
PU3/8	9.52	6.35	100	10	30	30	4.9
PU1/2	12.7	8.46	100	10	30	35	8.8

- Consulte para colores disponibles

MANGUERA DE POLIURETANO HELICOIDAL



Model	D1 (mm)	Maximum length L (m)	E (mm)	F (mm)
PUC0425	25	1-20	80	80
PUC0604	32	1-25	80	80
PUC0855	40	1-20	80	80
PUC0805	40	1-20	80	80
PUC1065	48	3-20	80	80
PUC1280	58	3-20	80	80
PUC1/4	32	1-20	80	80
PUC3/8	48	3-20	80	80
PUC1/2	58	3-20	80	80

SILENCIADORES

PSU Type Plastic Muffler



Code	Screw Thread (Size)	S (mm)
PSU-M5	M5	7
PSU-6	1/8"	13
PSU-8	1/4"	17
PSU-10	3/8"	25
PSU-15	1/2"	25
PSU-20	3/4"	
PSU-25	1"	

B Type Muffler



Code	Screw Thread (Size)	S (mm)
B-M5	M5	8
B-6	1/8"	12
B-8	1/4"	15
B-10	3/8"	19
-B15	1/2"	22
B-20	3/4"	27
B-25	1"	36

V Type Silencer



Model	Thread	S
V-M5	M5	8
V-6	1/8"	13
V-8	1/4"	16
V-10	3/8"	19
V-15	1/2"	24
V-20	3/4"	30
V-25	1"	36
V-32	1-1/4"	46
V-40	1-1/2"	53
V-50	2"	64

¡CONTÁCTANOS!



BLVD. LUIS DONALDO COLOSIO #7 COL. LOS NOGALES
27811 SAN PEDRO, COAHUILA, MÉXICO



LUNES - VIERNES DE 8:00AM A 8:00PM
SÁBADO DE 8:00AM A 7:00PM
DOMINGO DE 9:00AM A 3:00PM



(872) 110 18 56
(872) 772 85 87



ASESOR TÉCNICO
ING. DANIEL IVAN ESCOBAR LAZARIN

✉ descobar_lazarin@hotmail.com

📱 871 120 68 53